

AtlasIED Microphone Stations

To AtlasIED Valued Partners:

RE: Cleaning of AtlasIED Microphone Stations

AtlasIED has reviewed our microphone station products and has the following recommendations to ensure cleanliness and reduce the potential for germ transfer.

Microphone stations may be cleaned with commercially available household disinfectant wipes or cleansers, as long as they are not ammonia-based. When cleaning:

- Follow the disinfectant manufacturer's directions for use.
- Remove any excess liquid from the cloth/wipe to avoid getting cleaning solution into ports and other openings.
- Wipe screens with a clean microfiber cloth to remove any residual left by the cleaners.
- Do not spray disinfectant directly onto the screen. Spray onto cloth and then clean the screen.

Handheld microphones and gooseneck microphones can be wiped as above or lightly misted with commercially available household disinfectant spray. When spraying:

- Keep the spray nozzle 6-10" away from the microphone.
- Spray the mic completely but do not saturate the microphone. The internal components should not get wet.

AtlasIED cannot make a determination of the effectiveness of a given disinfectant product in fighting pathogens. Please refer to your local public health authority's guidance on how to stay safe from potential infection.

Please contact your customer service representative if you have any additional questions.

Respectfully,



James Treadway
Corporate Quality Assurance Coordinator
AtlasIED
9701 Taylorsville Rd
Louisville, KY 40299